## **BIG BIKE PARTS**

## **INSTALLATION INSTRUCTIONS**

 ${\rm Copyright}^{\odot} \ 2016 \ by \ Big \ Bike \ Parts, Inc. \ No \ part \ of \ this instruction \ sheet \ may \ be \ reproduced \ without \ the \ written \ permission \ of \ Big \ Bike \ Parts, Inc.$ 

PART NO. HD90-014BK

GAS TANK MINI BRA

## 4/26/2016

## HARLEY-DAVIDSON FLH 1993-NEWER

L	., = 0, = 0 = 0					
	TOOLS NEEDED:	5/32" ALLEN WRENCH	RUBBING ALCOHOL	LINT FREE TOWEL	THREAD LOCK COMPOUND	3/8" WRENCH
		PHILLIPS SCREWDRIVER				

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 15 TO 30 MIN.
USE A REMOVABLE THREAD LOCK ON ALL FASTENERS.
INSTALLATION:

- 1. USING A PHILLIPS SCREWDRIVER REMOVE THE SCREW AT THE BACK OF THE SEAT. SEE FIG. 1.
- 2. REMOVE THE SEAT. SET ASIDE.
- 3. USING A 3/8" WRENCH REMOVE THE BOLT HOLDING THE BACK OF THE CONSOLE TO THE BIKE. SEE FIG. 2.
- 4. ON THE FRONT OF THE CONSOLE USING A 5/32" ALLEN WRENCH REMOVE THE SCREW SHOWN IN FIG. 3.
- 5. OPEN THE FUEL DOOR AND REMOVE THE GAS CAP.
- 6. LIFT THE CONSOLE UP AND USING A LINT FREE TOWEL AND RUBBING ALCOHOL CLEAN THE BACK OF THE TANK AND UNDER EACH SIDE OF THE TANK.
- 7. LAY THE MINI BRA INTO PLACE ON THE GAS TANK AND USING THE SEAM ON THE BACK EDGE CENTER THE MINI BRA ON THE TANK.
- 8. REMOVE THE FILM FROM THE TWO 3" LONG PIECES OF HOOK ATTACHED TO THE BACK OF THE BRA AND ATTACH THEM AS SHOWN IN FIG. 4.
- 9. WITH THE BRA ATTACHED IN THE BACK PULL EACH SIDE TIGHT AND PLACE EACH PIECE OF HOOK UNDER THE SIDE OF THE TANK. SEE FIG. 5.
- 10. REINSTALL SEAT. ONCE THE SEAT IS ON READJUST THE BRA SO THAT IT IS TIGHT.
- 11. LET TAPE CURE FOR 24 HOURS AND THEN ADJUST TENSION OF MINI BRA TO TAKE OUT ANY LOOSE AREAS.

