

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2004 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

MASTER CYLINDER SWITCH BLOCK PART NO. 91-305

FITS: HARLEY DAVIDSON FXD 91-03;
FLT 97-03; FLH 97-03 AND XLH 86-03

TOOLS NEEDED: PHILLIPS SCREWDRIVER

CAUTION: BE SURE TO COVER THE TANK AND FENDERS WITH TOWELS. BRAKE FLUID WILL DESTROY THE PAINT IF IT DRIPS ON THE TANK OR FENDERS. ALSO, YOU SHOULD WRAP A TOWEL AROUND THE MASTER CYLINDER.

NOTE: THE FLUID LEVEL CHECK OPENING ON THE MASTER CYLINDER COVER WILL NOT BE OPERATIONAL AFTER INSTALLING THIS PART.

NOTE: SOME ACCESSORIES MAY REQUIRE THEIR OWN RELAY AND WIRING.

INSTALLATION:

1. USING THE PHILLIPS SCREWDRIVER REMOVE THE EXISTING MASTER CYLINDER COVER ON THE BIKE.
2. PLACE THE GASKET SUPPLIED ON THE MASTER CYLINDER, PLACE THE NEW SWITCH BLOCK ON TOP OF THE GASKET AND THEN PLACE THE ORIGINAL COVER ON TOP OF THE SWITCH BLOCK. TIGHTEN DOWN USING THE NEW LONGER SCREWS PROVIDED.
3. THE RED WIRE OFF OF THE SWITCH BLOCK IS TO BE CONNECTED TO YOUR ACCESSORY TERMINAL ON THE BIKE. THE OTHER TWO WIRES ARE TO CONNECT THE POWER WIRE FROM ACCESSORIES TO THE SWITCH.
4. CHECK TO MAKE SURE ALL ACCESSORIES WORK AND THAT THE MASTER CYLINDER DOES NOT LEAK BRAKE FLUID.