

HITCH RACK INSTALLATION INSTRUCTIONS

#GL18008

NOTE: The use of the following items GL18010, GL18008, QD1000 and PF1000 on any un-sprung trailer hitch (example: Voyager Trike Conversion Hitches, any hitch on a Can Am Spyder, or any other un-sprung hitch) will void the warranty. These items were not designed to handle the excessive vibration and impacts from un-sprung trailer hitches, and the items may be damaged when used on these applications.

This rack is designed to install and remove in seconds using the hitch pin clips provided while the receiver bracket stays permanently mounted to your tongue as shown.

INSTALLATION ON A RIVCO HITCH.

1. Remove the bolt securing the ball to the tongue.
2. Place the rack receiver bracket under the tongue, between the bolt & tongue as shown in photo #1.
3. Replace the ball and bolt, tighten securely.
4. Install the rack by sliding the 2 large pins on the rack into the receiver bracket, see photo #2, pushing firmly to compress the foam rubber sleeves far enough to allow the hitch pin clips to go thru the holes in the pins.
5. Clip and lock on the pins as shown.

ON OTHER BRANDS OF HITCHES

If your hitch is the type with a wider tongue or a platform type hitch you can turn the rack receiver bracket over and mount it as shown in photo #3

You may also purchase a second rack receiver bracket separately to mount to the tongue of your trailer or camper. This will allow you to take the rack with you while pulling your trailer or camper, then once you have parked your trailer and are ready for your day trips you can easily and quickly switch the rack and cooler from the trailer to you bike.

Thank you for purchasing a RIVCO product, enjoy!

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
262.763.8222 or rivcoproducts.com



#1



#2



#3